
Quick Start Guide

MT888




Manufacturer: Xiamen Hanin Co., Ltd.
Add: No.96, Rongyuan Road, Tong'an District, Xiamen, China, 361100
Web: www.idprt.com

Content

EN Start Guide ---------- 01

DE Start-Anleitung ---------- 10


EN Packing List




Printer




Thermal Bracket



USB Cable



Protective Case




Thermal Paper




Quick Start Guide

Appearance and Components


▪ Front View



▪ Left View



- **Inner View**



LED Indicator

White LED indicator is lighting:
Printer is turned on.

Green LED indicator is lighting:
Printer is in charging mode, and green LED indicator will be off when fully charged.

Red LED indicator is flashing:
Printer cover is opened.


Note： For more LED indicator and buzzer status, please contact customer service by email.

Print Self-test Page

In the turned on state, loading the thermal paper, press the power button 3 times to print a self-test page of the printer.

Power On


Hold down the power button for 3 seconds to turn on the printer.



⚠ To turn off the printer, also hold down the power button for 3 seconds.

Paper Loading

Put the thermal paper into the paper inlet in parallel with the thermal side down.
The printer will feed a distance automatically after detecting the paper.



Note: If the buzzer sounds once when paper feeding stops, it shows that the paper is loaded successfully. If the buzzer keeps beeping and the red LED is flashing, please open the cover and reload the paper.

Printing from Mobile Phone

1. APP Download
Scan the QR code to download the APP.

2. Connect with the printer
① Open App, click "Connect printer", and "Connect" with"MT888-XXXX" (XXXX are last four digits of Bluetooth address);

② If the APP can't find the printer, please open "Settings"-"Bluetooth" on your phone and connect with the printer first, and then return to APP and click "Connect".

3. Print
① Open the document you want to print, and copy/share it to APP. (Or click “Documents” on Home to choose the document.)
② Adjust it in Print preview, and click “Print” to print it.

Printing from Computer

1. Connect one side of the USB cable to the computer and the other side to the printer;

2. Turn on the printer;

3. Download the printer driver from the website: www.idprt.com/Driver/

And then install it on the computer;




4. Choose the document you want to print and print it via printer “MT888”.


Battery Charging

When the printer is in low power, the green LED indicator will flash. Please use matching USB cable to charge in time. If you continue printing, the printer may shut down automatically.

① Charging by computer



② Charging by adapter



Precautions


1. The best operating temperature is 0°C~40°C, if the environmental temperature is too low or too high, the print quality may be affected.

2. Please do not use the unofficial paper to ensure the print quality.

3. During printing, the area around the print head is very hot. Do not touch it to avoid burns.

4. Do not pull out paper by force during printing, or else it may damage the printer.


DE Packliste




Drucker




Thermische Halterung



USB Kabel



Schutzhülle




Thermopapier




Schnellstart-Anleitung

Erscheinungsbild und Komponenten


▪ Vorderansicht



▪ Linke Ansicht



- **Innenansicht**



LED-Anzeige

Die weiße LED-Anzeige leuchtet:
Der Drucker ist eingeschaltet.

Die grüne LED-Anzeige leuchtet:
Der Drucker befindet sich im Aufladem odus, und die grüne LED-Anzeige erlischt, sobald der Drucker komplett aufgeladen ist.

Die rote LED-Anzeige blinkt:
Der Druckerdeckel ist geöffnet.


Hinweis:
Für weitere LED-Anzeigen und den Summerstatus kontaktieren Sie bitte unseren Kundenservice per E-Mail.

Seite Selbsttest drucken

Drücken Sie im eingeschalteten Zustand, beim Einlegen des Thermopapiers, 3 Mal die Power-Taste, um eine Selbsttestseite des Druckers zu drucken.

Einschalten

Halten Sie die Power-Taste 3 Sekunden lang gedrückt, um den Drucker einzuschalten.




⚠ Um den Drucker auszuschalten, halten Sie ebenfalls die Power-Taste für 3 Sekunden gedrückt.

Papier einlegen

Legen Sie das Thermopapier mit der Thermoseite nach unten parallel in den Papiereinzug ein.

Der Drucker zieht automatisch einen Abschnitt ein, nachdem er das Papier erkannt hat.



Hinweis: Falls der Summer einmal ertönt, wenn der Papiereinzug stoppt, bedeutet dies, dass das Papier erfolgreich eingelegt wurde. Sollte der Summer weiterhin piepsen und die rote LED blinken, öffnen Sie bitte die Abdeckung und legen Sie das Papier erneut ein.

Drucken vom Mobiltelefon

1. APP herunterladen
Scannen Sie den QR-Code, um die APP herunterzuladen.

2. Verbinden Sie sich mit dem Drucker

① Öffnen Sie die App, klicken Sie auf "Drucker verbinden" und "Verbinden" mit "IDPRT MT888-XXXX" (XXXX sind die letzten vier Ziffern der Bluetooth-Adresse);

② Falls die APP den Drucker nicht finden sollte, öffnen Sie bitte "Einstellungen"-" Bluetooth" auf Ihrem Telefon und verbinden Sie sich zuerst mit dem Drucker, gehen Sie dann zurück zur APP und klicken Sie auf "Verbinden".

3. Drucken

① Öffnen Sie das Dokument, welches Sie drucken möchten, und kopieren Sie es in die APP. (Oder klicken Sie auf "Dokumente" auf der Startseite, um das Dokument auszuwählen.)

② Stellen Sie es in der Druckvorschau ein und klicken Sie auf "Drucken", um es zu drucken.

Drucken vom Computer

1. Verbinden Sie eine Seite des USB-Kabels mit dem Computer und die andere Seite mit dem Drucker;

2. Schalten Sie den Drucker ein;

3. Laden Sie den Druckertreiber von der Website herunter:
www.idprt.com/Driver/
Und dann installieren Sie ihn auf dem Computer;


4. Wählen Sie das Dokument, welches Sie drucken möchten und drucken Sie es mit dem Drucker "IDPRT MT888".

Aufladen der Batterie


Sollte der Drucker zu wenig Strom haben, blinkt die grüne LED-Anzeige. Bitte benutzen Sie rechtzeitig das passende USB-Kabel zum Aufladen.

Falls Sie weiterdrucken, schaltet sich der Drucker möglicherweise automatisch ab.

① Aufladen mit dem Computer



② Aufladen mit Adapter



Precautions

1. Die beste Betriebstemperatur beträgt 0°C~40°C. Falls die Umgebungstemperatur zu niedrig oder zu hoch ist, kann die Druckqualität beeinträchtigt werden.

2. Bitte benutzen Sie kein nicht offizielles Papier, um die Druckqualität zu gewährleisten.

3. Während des Drucks ist der Bereich um den Druckkopf sehr heiß. Berühren Sie ihn nicht, um Brandverletzungen zu vermeiden.

4. Ziehen Sie das Papier während des Druckens nicht mit Gewalt heraus, da dies den Drucker beschädigen könnte.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio com munications.

Please Scan QR Code to Get 24h After-sales Technical Support Service



Customer Service Email：technical@idprt.com